

**DEVELOPMENT NEAR ROAD OR RAIL NOISE**

20.1 Development Near Road or Rail Noise

## 20.1 DEVELOPMENT NEAR ROAD OR RAIL NOISE

### Objectives

- 1 *To ensure that excavation, earthworks, demolition and construction does not adversely impact on the function or safety of the rail corridor or busy roads.*
- 2 *To ensure noise and vibration mitigation measures are implemented in development adjacent to rail and road corridors.*
- 3 *To address air quality issues associated with rail and road corridors, and minimise their effect upon adjacent development.*
- 4 *To ensure development does not reduce the safety of users of the site or the road or rail corridor.*
- 5 *To minimise the impact of external noise from road or rail corridors and facilitate comfortable living conditions for residents.*

### Controls

- 1 All development that is in, or immediately adjacent to, the rail corridor or a busy road must be designed in accordance with NSW Department of Planning 'Development Near Rail Corridors and Busy Roads - Interim Guidelines, December 2008' (DNRCBR 2008).  
**Note:** Under NSW DNRCBR 2008, busy roads include:
  - Pacific Highway;
  - Ryde Road;
  - Mona Vale Road;
  - Main Road 328, Section of Boundary Street, between Pacific Highway and Babbage Road, within the Local Centre boundary; and
  - Secondary Road 2043, Section of Horace Street, Link Road, Killeaton Street within the Local Centre boundary.**Note:** Under DNRCBR 2008, the rail corridor refers to the North Shore rail line.  
**Note:** SEPP Infrastructure will also apply
- 2 Buildings must be designed to minimise the impact of noise through planning, construction and materials in accordance with the relevant acoustic standards in relation to noise transmission from traffic:
  - i) *AS3671-1989: Acoustics- Road traffic noise intrusion- Building siting and construction.*
  - ii) *AS2107-2000: Acoustics- Recommended design sound levels and reverberation times for building interiors.*
- 3 On lots adjoining the rail corridor and/or a busy road, landscaping is to be designed to:
  - i) create a setting for the building by planting tall trees which contribute to the tree canopy; and
  - ii) be durable and suited to the conditions of the road and railway environment.
- 4 Where dwellings are located on busy roads incorporate the following into the design of the development to reduce traffic noise within the dwelling:
  - i) cavity brick walls;
  - ii) double glazing;
  - iii) solid core doors;
  - iv) concrete floors;
  - v) recessed balconies;
  - vi) located habitable rooms (bedroom, living rooms) away from the road / noise source;
  - vii) use of landscaping mounds and vegetation as noise buffers.

## 20.1 DEVELOPMENT NEAR ROAD OR RAIL NOISE (continued)

### Controls

- 5 Residential fencing or masonry walls to a busy road must be a maximum of 1.8m high, with a minimum 2m setback from the front boundary to provide a landscape zone. This landscape zone must incorporate shrubs and trees that screen the wall from the road.




Figure 20.1-1:  
Fencing for development facing a busy road.

THIS PAGE IS INTENTIONALLY BLANK